

METRAHIT IM XTRA & METRAHIT IM E-DRIVE **Isolation Tester, Milliohmmeter, TRMS Multimeter, Short-Circuited Coil Tester**

3-447-034-03 3/6.19

- Insulation resistance measurement up to 3.1 $G\Omega$ with interference voltage detection, test voltages: 50, 100, 250, 500 and 1000 V per DIN EN 61557-2 / VDE 0413-2
- DAR: dielectric absorption rate, PI: polarization index
- 4-wire milliohm measurement (Kelvin connection), 200 mA or 1 A measuring current for precise measurement of extremely small resistances with a resolution of 1 $\mu\Omega$
- 2-wire RIo measurement with 200 mA test current per DIN EN 61557-4 / VDE 0413-4
- Short-circuited coil test with 1000 V and optional COIL adapter
- Multifunctional measuring instrument (V, A, Ω, F, Hz, %, RPM, °C/°F)
- TRMS $_{\mbox{\scriptsize AC/AC+DC}}$ measurement for current/voltage value up to 10/100 kHz
- Low-pass filter can be activated, 1 kHz (-3 dB) in the V AC, AC+DC range
- Direct current measurement, 10 nA to 1 A
- Current measurement with clamp sensors transformation ratio can be adjusted with CLIP from 1:1 to 1:1000 and is taken into account in the amperage display
- Capacitance measurement
- Precision temperature measurement °C, and °F for RTD and TC-K sensors
- Diode measurement ($I_K = 1 \text{ mA}$, U_{Flow} up to 5.1 V) and continuity testing
- Acoustic signals
- Acquisition of min./max. values, DATA Hold
- Data logger thanks to integrated memory module and real-time clock, individual measurements as well
- Push/print function transfers measured values to software by pressing a key
- Programmable sequences for test routines
- Color graphic display
- Modular supply power: standard quick-change rechargeable lithium battery, optional WPC module for inductive charging and mains module with USB port, change without interrupting the measuring circuit thanks to touch protected module socket
- Automatic blocking sockets for the current input
- Remote probe with START (ISO) and STORE keys
- Housing with IP52 protection, dust and splash protected, replaceable rubber holster
- Interfaces: Bluetooth or WLAN integrated, USB with optional mains module
- **IZYTRONIQ** windows software for documentation, preparation of test reports and graphic evaluation of measurements

CE

600 V CAT IV 1000 V CAT III











reddot award 2018 winner industrial design

Applications

The METRAHIT IM XTRA and the METRAHIT IM E-DRIVE are portable, extremely rugged multimeters designed for use in the field. They're suitable for maintenance, service and diagnosis at electric machines, drive units and systems, for example in automotive, energy and automation applications.

METRAHIT IM XTRA and METRAHIT IM E-DRIVE multimeters are all-inone instruments: insulation tester, milliohmmeter, short-circuited coil tester and universal multimeter. They're ideal for safety testing and diagnosis at electric and hybrid vehicles, as well as all types of electric machines.

The METRAHIT IM XTRA and the METRAHIT IM E-DRIVE make it possible to test coils for short-circuits within an inductance range of 10 µH to 50 mH (at 100 Hz) in combination with the optional COIL Adapter 50mH. This range corresponds to motors in accordance with DIN standards with power ratings of roughly 15 kVA to 80 MVA. A universal adapter for motors with medium power ratings is in preparation.

Features

Insulation Resistance Measurement with Interference Voltage Detection

Insulation resistance measurement with test voltages of 50 to 1000 V. If interference voltage of greater than 15 V AC or 25 V DC is detected during insulation measurement, an error message appears briefly at the display, after which automatic switching to $\mathsf{TRMS}_{\mathsf{AC+DC}}$ voltage measurement at 1 $\mathsf{M}\Omega$ takes place.

Polarization Index (PI):

When test voltage is applied, insulation resistance is measured after one minute and after ten minutes. The polarization index is the ratio which results from the two measured values. In the case of electric drive units, a value of at least 2 indicates intact insulation and a value of greater than 4 indicates very good insulation.

Absorption Index (DAR)

Practically speaking, the absorption index test is a quick polarization index measurement. The ISO values measured after 30 and 60 seconds are used to generate a ratio.

Isolation Tester, Milliohmmeter, TRMS Multimeter, Short-Circuited Coil Tester

Kelvin Connection for 4-Wire Measurement (4-L) (milliohm measurement)

The 4-wire measurement compensates for influences resulting from cable and contact resistances which must not be neglected when measuring very small resistances. Measuring current can be set to 200 mA or 1 A. In this way, even extremely small contact resistances can be measured, for example at welded and riveted joints and on aircraft outer skins (lightning protection and wick test), or equipotential bonding is measured in accordance with UN ECE R100 in hybrid and electric vehicles.

2-Wire Rlo Measurement with 200 mA Test Current per EN 61557 / VDE 0413

Low-resistance measurement per EN 61557-4 / VDE 0413, part 4, for earth, protective and equipotential bonding conductors.

RMS Value with Distorted Waveform

The utilized measuring method allows for waveform-independent TRMS measurement of periodic quantities (AC) and pulsating quantities (AC and DC) for voltage and current at up to 100 kHz.

Activatable Filter for V AC Measurement

A 1 kHz low-pass filter can be activated if required, for example when measuring cables with parasitic external signals. The input signal is checked by a voltage comparator for dangerous voltages as long as the low-pass filter is activated, and these are indicated at the display if applicable.

Diode Testing with Constant Current $I_k = 1 \text{ mA}$

Testing of the polarity of diodes and checking for short-circuits and interruptions in electrical circuits. The test voltage source makes it possible to measure LEDs and reference diodes up to 4.5 V, e.g. also white LEDs.

Fast Acoustic Continuity Test $I_k = 1 \text{ mA}$

Testing for short-circuiting or interruption in the \mathbb{Q}) switch position. The threshold value for acoustic signaling can be set to 1, 10, 20, 30, 40 or 90 Ω .

Automatic/Manual Measuring Range Selection

Measured quantities are selected with the rotary switch.

The measuring range can be automatically matched to the measured value, or selected manually for quick, repetitive measurements.

Color Graphic Display

A high-resolution transmissive 3½" TFT color graphic display with 320 x 480 dots is used for measured values and menu navigation. The display is easily readable from all directions, as well as under difficult lighting conditions (controllable with light sensor). Graphic representation permits user-friendly menu navigation including help texts.

Analog Bar Graph for Quick Trend Displays

The bar graph (with additional negative axis range for zero-frequency quantities) permits faster detection of measured value changes as compared with digital value displays.

Display Resolution

High resolution with 30,000 digits and a basic accuracy of 0.15%.

Automatic Storage of Measured Values

The DATA HOLD function automates the storage of measured values after they have settled in. A patented process assures that random values are not saved to memory in the case of rapidly changing measured quantities, but rather the actual measured value. The stored measured value is displayed as a digital value. The bar graph continuously indicates the momentary measured value.

Overload Protection

Overload protection safeguards the instrument in all measuring functions for up to 1000 V. Voltages of greater than 1000 V and currents of greater than 1 A are indicated acoustically. FUSE appears at the display if the fuse for the current or $m\Omega$ measurement input blows.

Battery Charge Level - Power Saving Circuit

The battery charge level is accurately indicated in the graphic display.

The device is switched off automatically if the measured value remains unchanged for a period of between 10 and 59 minutes (adjustable), if none of the controls are activated during this time and continuous operation is not activated.

Automatic Blocking Sockets (ABS) *

All current ranges are implemented via a single connector jack which prevents any possibility of operator error.

The automatic blocking sockets prevent incorrect connection of the measurement cables, as well as selection of the wrong measured quantity. Danger to the user, the instrument and the device under test resulting from operator error is thus ruled out.

* Patented (patent no. EP 1801 598 and US 7,439,725)

Housing and Protective Cover for Harsh Conditions

- New housing design
- Separate fuse compartment
- Quick-change rechargeable battery

The instrument is protected against damage in the event of impacts or dropping by means of a soft rubber cover with tilt stand. The rubber material also assures that the instrument doesn't wander if it's set up on a vibrating surface

Data Interfaces

The instrument can be remote configured and momentary and saved measurement data can be read out via a bidirectional wireless interface, Bluetooth or WLAN, or the USB port at the optional mains module. IZYTRONIQ software is required to this end.

Interface protocol and device driver software for **LabVIEW** (National InstrumentsTM) are available upon request.

Voluntary Manufacturer's Guarantee

36 months for materials and workmanship. 1 year for calibration.

DAkkS calibration certificate

The **METRAHIT IM XTRA** multimeter is furnished with a DAkkS calibration certificate, which is also recognized internationally (EA, ILAC).

After the user-specified calibration interval has elapsed (recommended interval: 1 to 3 years), the multimeter can be inexpensively recalibrated in our own DAkkS calibration laboratory.

Isolation Tester, Milliohmmeter, TRMS Multimeter, Short-Circuited Coil Tester

Overview of Included Features

Function	METRAHIT IM XTRA (BT) METRAHIT IM E-DRIVE (BT)
V_{DC} (Ri = 9 M Ω)	•
V_{AC} / Hz TRMS (Ri = 9 M Ω)	1 kHz) filter
V_{AC+DC} TRMS (Ri = 9 M Ω) ¹	1 kHz) filter
V_{AC+DC} TRMS (Ri = 1 M Ω) R _{ISO} range (interference voltage)	•
Hz (V _{AC})	300 kHz
V _{AC, AC+DC} bandwidth	100 kHz
A _{DC, AC, AC+DC} / Hz TRMS	10 nA 1 A
Fuse	1 A / 1000 V - 30 kA
Current sensor transformation ratio >C	1 mV : 1 • 10 • 100 • 1000 mA
Hz (A AC)	30 kHz
Insulation resistance RISO: test voltages	50 • 100 • 250 • 500 • 1000 V
Short-circuited coil test (1 kV) with COIL adapter	Option
Duty cycle measurement as %	•
Speed measurement in RPM	•
Resistance Rlo with 200 mA per EN 61557 / VDE 0413	•
Milliohm with 4-wire method, $m\Omega$ with 200 mA	•
Milliohm with 4-wire method, mΩ with 1 A pulse	•
Fuse	1 A / 1000 V - 30 kA
Resistance Ω	•
Continuity (1)	•
Diode 5.1 V-▶	•
Temperature: °C/°F TC type K and Pt100/1000 ²	•
Capacitance	•
Min-Max / data hold	•
Test sequence	20 steps
64 MBit memory ³	•
Bluetooth interface	METRAHIT IM XTRA BT METRAHIT IM E-DRIVE BT
WIFI interface	Option
3.5" TFT color graphic display	•
2-key Remote probe: start/stop and store	•
Quick-change battery with USB charging	•
Mains module with electrical isolation and USB charger	Option
WPC quick change battery for inductive charging	Option
Protection	IP 52
Measuring category	1000 V CAT III, 600 V CAT IV

Due to the system, the DC component indicated in the smallest measuring range (300 mV) has an offset. For a precise measurement of the DC component, please select measuring function VDC.

with optional temperature sensors

Standard Equipment (depending on Device Variant)

- 1 METRAHIT IM XTRA or METRAHIT IM E-DRIVE multimeter with rubber holster
- 1 Remote probe with start/stop and store/send functions
- 1 Type KS17-2 cable set: 1 pair of safety measurement cables with 4 mm test tip red/black
- 1 Type KC4 Kelvin clip, 1 pair (only METRAHIT IM XTRA)
- 1 Type KC&S Kelvin clip and Kelvin probe (only METRAHIT IM E-DRIVE)
- 1 Quick change, rechargeable lithium polymer battery with micro USB charging socket
- 1 USB mains power pack (5 V DC, 2 A) with cable and micro USB charging plug
- 1 DAkkS calibration certificate
- 1 Hard case for the multimeter and accessories
- 1 Condensed operating instructions, German/English
- Comprehensive operating instructions in German and English available on the Internet for download at www.gossenmetrawatt.com
- 1 Card with registration key for the software



Overview Supply

Accessories	Туре	Article No.	M273S	M274S
METRAHIT IM XTRA		M273D	Х	
METRAHIT IM E-DRIVE BT		M274B		Х
Lilon module & USB charger	Z270A+		X	X
Mains module with electrical isolation and USB charger			0	0
Remote probe	Z270S	Z270S	Χ	X
Cable set		GTY362003		
	KS17-2	P0002	Χ	X
1 pair Kelvin clips	KC4	Z227A	Χ	0
1 pair Kelvin probes	KC27	Z227B	0	0
1 Kelvin clip &				
1 Kelvin probe	KC&S	Z227C	_	X
Hard case	HC40	Z270K	Χ	X
COIL Adapter 10 µH ,,, 50 mH	COIL Adapter 50mH	Z270F	0	0
COIL Adapter 10 µH ,,, 500 mH	COIL Adapter XTRA	Z270M	0	0
IZYTRONIQ Business Starter		S101S &		
Licence	S101S & Z956A	Z956A	X	X

Leaend

X = Standard

O = Option

- = not possible, not provided for

For 300,000 measured values, sampling rate adjustable from 0.1 seconds to 9 hours

Isolation Tester, Milliohmmeter, TRMS Multimeter, Short-Circuited Coil Tester

Characteristic Values

Meas.		Resol	ution at	lancet lan		Intrinsic	-	nder Reference	Conditions	Over	rload_	
Func.	Measuring Range	Upper Ra	ange Limit	input im	pedance	20,000		rdg. + d)	20,000	Capa	city ²	
(input)		30.000	3000			30,000	3000	30,000 ~ 1,11	30,000 = 1, 11	Value	T:	
	000 1/	,	3000		~/≅				₹ ,	Value	Time	
	300 mV	10 μV		9 ΜΩ	9 MΩ // < 50 pF	0.15 + 10 10				1000 V DC		
	3 V	100 μV		9 ΜΩ	9 MΩ // < 50 pF	0.15 + 10				AC		
V	30 V	1 mV		9 ΜΩ	$9 \text{ M}\Omega$ // $< 50 \text{ pF}$	0.15 + 10		0.5 + 30	0 1.0 + 30	RMS	Cont	
	300 V	10 mV		9 ΜΩ	$9 \text{ M}\Omega$ // $< 50 \text{ pF}$	0.2 + 20				sine		
	1000 V	100 mV		9 ΜΩ	$9 \text{ M}\Omega$ // $< 50 \text{ pF}$	0.2 + 20				ь		
				Voltage drop at a	pprox. range limit			∼ 1, 11	≂1,11			
	300 μΑ	10 nA		7(O mV	0.25 + 10		1+ 30 10)				
	3 mA	100 nA			5 mV				-			
Α	30 mA	1 μΑ			0 mV			10)	1.0 + 30 d	0.3 A	Cont	
	300 mA	10 μΑ) mV	0.15 + 10		$0.5 + 30^{10}$	1.0 1 00 0			
	1 A	100 μΑ			2 V			-		1 A	5 min	
								~ 1, 11 ≂ 1, 11		IA	JIIII	
	Factor: 1:1/10/100/1000	Measure	ment input	Input im	pedance							
A >C	0.3, 3, 30, 300 A		300 mV					0.5 + 30 d	1.0 + 30 d	Measurem	ent input	
® V _{ac} / V _{ac}	3, 30, 300, 3 k A		3 V	voltage measuremer	nt input approx. 9 M Ω V socket)	0.15 + 10 ¹⁰	Plus curr	ent transformer	clamp error	1000 V	Max. 10	
-1.0				Open-circuit voltage	Meas. current at range limit	±(% rd	g. + d) 3000					
mO @	3 mΩ		0.001 mΩ	2.8 3.8 V	1 A		1.0 + 20					
m Ω @ . A pulse	30 mΩ		0.001 mΩ	2.8 3.8 V	1 A					± 0.6 V ¹⁴	Cont.	
(4-wire)	300 mΩ		0.01 mΩ	2.8 3.8 V	1 A		0.5 + 7			± 0.0 v	JUIL	
	30 mΩ		0.1 mΩ	> 4 V	200 mA							
mΩ@	300 mΩ						0.5 . 7			± 0.6 V ¹⁴	0	
200mA (4-wire)			0.1 mΩ	> 4 V	200 mA		0.5 + 7			± 0.6 V · ·	Cont	
, ,	3 Ω		1 mΩ	> 4 V	200 mA							
mΩ@ 20 mA (4-wire)	30 Ω		10 mΩ	> 4 V	20 mA		0.5 + 7			\pm 0.6 V ¹⁴	Cont	
	@ 200mA: 3 Ω		1 mΩ	> 4 V	200 mA		2.5 +10 ¹⁰			10		
R _{Lo} 2L N61557	@ 20mA: 30 Ω		10 mΩ	> 4 V	20 mA		2.5 +10 ¹⁰			\pm 0.6 V 15	Cont	
	300 Ω	10 mΩ		< 1.4 V	Approx. 300 μA	$0.2 + 30^{10}$	2.0 1 10					
	3 kΩ	100 mΩ	_	< 1.4 V	Approx. 100 µA	$0.15 + 10^{10}$				1000 V DC AC	1000 V	
		1 Ω	_	< 1.4 V								1000 V
Ω			_		Approx. 10 μA	0.15 + 10						
(2-wire)	300 kΩ	10 Ω		< 1.4 V	Approx. 1 μA	0.15 + 10					- AC	Max
	3 ΜΩ	100 Ω		< 1.4 V	Approx. 0.2 µA	0.5 + 10				AC RMS	10 s	
	30 MΩ	1 kΩ		< 1.4 V	Approx. 0.03 μA	2.0 + 10				sine		
n (1)	300 Ω		100 mΩ	Approx. 3 V	Approx. 1 mA constant		1 + 5 10					
₩	4,5 V ³		1 mV	Approx. 8 V			0.5 + 2					
				Discharge resistance	U _{0 max}		±(% rdg. +	. d)				
	30 nF		10 pF	10 MΩ	0.7 V		1.5 + 10 ^{4 10}			400014		
	300 nF		100 pF	1 ΜΩ	0.7 V		1 + 6 ⁴			1000 V DC		
F	3 μF		1 nF	100 kΩ	0.7 V		1 + 6 4			AC	Max. 1	
•	30 μF		10 nF	12 kΩ	0.7 V		1 + 6 4			RMS	TTI CONT.	
	300 μF		100 nF	3 kΩ	0.7 V		5 + 6 ⁴		_	sine		
	σου μι		100 111	0 1/32	f _{min} ⁵		±(% rdg. +	ď				
	300 Hz	0.01 Hz		1	'min		±(/0 lug. +	. uj		U= лл б		
Hz (V)/			-	-	1.11=					Hz (V) ⁶ : Hz (A >c) ⁶ :		
Hz (A)	3 kHz	0.1 Hz	-	-	1 Hz	($0.05 + 5^8$			1000 V	Max. 10	
lz (A 🖔)	30 kHz	1 Hz										
(V.)	300 kHz	10 Hz			20 Hz					Hz (A): ⁷		
			Resolution	Voltage MR ¹³	Frequency MR	=	±(% v. MR + .	d)				
	10.0 90.0			0.1/40	15 Hz 1 kHz		0.2% rdg. + 8 d			1000 V		
	10.0 90.0			3 V AC	> 1 kHz 4 kHz		0.2% MR/kHz +	8 d		DC AC RMS		
%	5.0 95.0		0.1%		15 Hz 1 kHz		0.2% rdg. + 8				Cont	
	15.0 85.0		1	30 V AC	> 1 kHz 4 kHz		0.2% MR/kHz +			sine		
DDAA			1 004		> 1 N1Z 7 N1Z		0.2 /0 IVII V KI IZ +	- u				
RPM	30 30,000		1 RPM	1				0				
						=	±(% rdg. +	K) ⁹				
	Pt100 - 200 +850 °C					(0.5% + 1.5					
							5.0 /0 1 T.U			1000 V		
°C / °F	Pt1000 - 200	0.1 °C				(0.5% + 1.5			DC/AC	Max. 1	
<i></i>	+600 -6	0.1					2.070 1 1.0			RMS	IVIGA. IV	
	K – 250 (NiCr-Ni) +1372 °C					1	1% + 5			sine		

^{15 ...} $\underline{45}$... $\underline{65}$ Hz ... 100 kHz sinusoidal. For influence see page 5. At 0 ° ... + 40 °C

Key: d = digit(s), MR = measuring range, rdg. = reading (measured value)

Display of up to max. 5.1 V, "OL" in excess of 5.1 V.

Applies to measurements at film capacitors during battery operation

Lowest measurable frequency for sinusoidal measuring signals symmetrical to the zero point

Overload capacity of the voltage measurement input:

overload capacity of the overlage integration from the power limiting: frequency x voltage max. $6 \times 10^6 \text{ V} \times \text{Hz}$ at > 100 V Overload capacity of the current measurement input:

See current measuring ranges for maximum current values.

Input sensitivity, sinusoidal signal: 10% to 100% of the voltage or current measuring range, restriction in mV

measuring range: 30% rdg. The voltage measuring ranges with max. 10 kHz apply in the A measuring range.

⁹ Plus sensor deviation 10 With ZERO function active

Accuracy applies as from 1 % of MR; due to the TRMS converter, values < 50 digits are suppressed in the zero point.

^{12 10} minute cool-down period

To minute cool-cowin period

Required signal range: 30% to 100% of the voltage measuring range

14 The integrated FF1A/1000 V fuse blows in the event of overloading

The integrated FF0.315A/1000 V fuse blows in the event of overloading

Isolation Tester, Milliohmmeter, TRMS Multimeter, Short-Circuited Coil Tester

Insulation Measurement

Measuring Range	Resolution	Nominal Voltage U _{ISO}	Intrinsic Uncertainty at Reference Conditions ±(% rdg. + d)
3 1000 V ≃ ¹		$Ri = 1M\Omega$	3 + 3
300 kΩ	0.1 kΩ	50/100/250/500 V	2 + 10
3 ΜΩ	1 kΩ	50/100/250/500/1000 V	2 + 10
30 MΩ	10 kΩ	50/100/250/500/1000 V	2 + 10
300 MΩ	100 kΩ	50/100/250/500/1000 V	5 + 10
3000 MΩ	1 MΩ	250/500/1000 V	5 + 10

¹ TRMS interference voltage measurement (V $_{AC+DC}$) with 1 M Ω input resistance, frequency response width: > 65 ... 500 Hz, accuracy: 3% + 30 digits

Measuring Function	Nom. Voltage U _N	Open- Circuit Voltage U _o Max.	Nom. Cur- rent I _N	Short- Circuit Cur- rent I _k	Acoustic Signal for	Overload Value	Capacity Time
$U_{int.}/$ $M\Omega_{@}U_{ISO}$	_	_	_	_	U > 1000 V	1000 V≅	Cont.
$M\Omega_{@}U_{ISO}$	50 100 250 500 V 1000 V	1.2x U _{Iso} 1.12x U _{Iso}	1.0 mA	< 1.4 mA	U > 1000 V	1000 V≅	10 s

Short-Circuited Coil Test (only with optional COIL adapter)

Measuring Range	Resolution	Nominal Voltage U _{ISO}	Intrinsic Uncertainty at Reference Conditions ±(% rdg. + d)
0.3 1000 V ≅ ¹		$Ri = 1M\Omega$	3 + 30 > 100 digits
10.0 30.9 µs	0.1 [µs]	1000 V	10 + 5 digits
31 250 µs	1 [µs]	1000 V	10 + 3 digits

 $^{^{1}}$ TRMS interference voltage measurement (V $_{AC+DC}$) with 1 $M\Omega$ input resistance, frequency response width: $>65\ldots500$ Hz, accuracy: 3%+30 digits

Short-circuited coil test within an inductance range of: 10 μH to 50 mH @ 100 Hz

Internal Clock

Time format DD.MM.YYYY hh:mm:ss

Resolution 0.1 s (measured values time stamp)

Accuracy ±1 minute per month

Temperature

influence 50 ppm/K

Reference Conditions

Ambient temperature +23 °C ± 2 K Relative humidity +23 °C ± 2 K +23 °C ± 2 K

Measured quantity

frequency 45 Hz ... 65 Hz Measured quantity waveform Sinusoidal Supply voltage 4.0 V \pm 0.1 V

Influencing Quantities and Influence Error

Influencing Quantity	Sphere of Influence	Measured Quantity / Measuring Range ¹	Influence Error (% rdg. + d) / 10 K
		V 	0.2 + 5
		$_{ m V} \simeq$	0.4 + 5
	0 °C +21 °C and +25 °C +40 °C	$300~\Omega$ $3~\text{M}\Omega$	0.5 + 5
		30 MΩ	1 + 5
Temperature		mA/A 	0.5 + 5
		mA/A ≃	0.8 + 5
		30 nF 300 μF	2 + 5
		Hz	0.2 + 5
		°C/°F (Pt100/Pt1000)	0.5 + 5

With zero balancing

Frequency Influence for V_{AC} V_{AC+DC} Voltage Ranges

		Deviation ¹	
Frequency Range	300 mV range ± (% rdg. + d)	3 V, 30 V, 300 V range 2 ± (% rdg. + d)	1000 V range ² ± (% rdg.)
15 Hz 45 Hz	2 + 30	2 + 30	2 + 30
> 65 Hz 1 kHz	0.5 + 30	0.5 + 30	1 + 30
> 1 kHz 10 kHz	2 + 30	1.5 + 30	10 + 30
> 10 kHz 20 kHz	3 + 30	1.5 + 30	_
> 20 kHz 50 kHz	3 + 30	5 + 30	_
> 50 kHz 100 kHz	10 + 30	10 + 30	_

For sinusoidal input signals > 10% to 100% of the range (mV range: as of 30% of range, at 1% to 10% of the range: f < 50 kHz, intrinsic error increased by 0.2% of the upper range limit.

Frequency Influence for I_{AC} / I_{AC+DC} Current Measuring Ranges

	Influence Error ¹				
Frequency Range	300 μ A to 300 mA \pm (% rdg. + digits)	1 A range ± (% rdg. + digits)			
15 Hz 45 Hz	2 + 30	2 + 30			
> 65 Hz 1 kHz	1 + 30	1 + 30			
> 1 kHz 2 kHz	1 + 30	1 + 30			
> 2 kHz 5kHz	1 + 30	3 + 30			
> 5 kHz 10 kHz	5 + 30	5 + 30			

¹ For sinusoidal input signals > 10% to 100% of the range.

Influencing Quantity	Sphere of Influence	Measured Quantity / Measuring Range	Influence Error ¹
Creat Footor CF	1 3	V	± 1% rdg.
Crest Factor CF	> 3 5	V ∼, A ∼	± 3% rdg.

¹ Except for sinusoidal waveform

Influencing Quantity	Sphere of Influence	Measured Quantity	Influence Error
Relative Atmospheric Humidity	75% 3 days instrument off	V, A, Ω, F, Hz, °C	1 x intrinsic uncertainty
Battery Voltage	3.6 4.2 V	ditto	Included in intrinsic uncertainty

Influencing Quantity	Sphere of Influence	Measured Qty. / Measuring Range	Damping
	Interference quantity max. 1000 V \sim	V 	> 90 dB
Common Mode Interference		3 √ ~	> 90 dB
Voltage	Interference quantity max. 1000 V ~ 50 Hz 60 Hz, sinusoidal	30, 300 V ∼	> 150 dB
	00 Hz III 00 Hz, 0.110001da	1000 V ∼	> 150 dB
Series Mode Interference Voltage	Interference quantity: V ~ , respective nominal value of the measuring range, max. 1000 V ~ , 50 Hz 60 Hz sinusoidal	V 	> 50 dB
,	Interference quantity max. 1000 V —	V ~	> 50 dB

Overload capacity of the voltage measurement input: power limiting: frequency x voltage max. 6 x 10⁶ V x Hz at > 100 V

Isolation Tester, Milliohmmeter, TRMS Multimeter, Short-Circuited Coil Tester

Response Time (after manual range selection)

Measured Quantity / Measuring Range	Digital Display Response Time	Measured Quantity Jump Function
V , V ∼ A , A ∼	1.5 s	From 0 to 80% of upper range limit value
300 Ω 3 MΩ	2 s	
30 MΩ, MΩ _@ U _{ISO}	Max. 5 s	
Continuity	< 50 ms	From ∞ to 50% of upper range limit value
°C (Pt 100)	Max. 3 s	or apportange innit value
→	1.5 s	
30 nF 300 μF	Max. 5 s	From 0 to 50%
>10 Hz	1.5 s	of upper range limit value

Fuse

Current measuring

ranges

F1: FF 1 A/1000 V AC/DC,

& 4L m Ω measuring

6.3 x 32 mm

ranges

Fuse with breaking capacity of 30 kA at 1000 V AC/DC, protects the current mea-

surement input in the 300 µA to 1 A

 $2L \, m\Omega$ measuring ranges

F2: FF 0,315 A/1000 V 6.3 x 32 mm

Fuse with breaking capacity of 30 kA at

1000 V AC/DC

Display

TFT color graphic display (55 x 36 mm) with analog and digital display including unit of measure, type of current and various special functions

Background Illumination

Activated background illumination can be regulated by means of a light sensor.

Analog Bar Graph

Scaling

Polarity display With automatic switching

40 measurements per second and display Measuring rate

Digital Measured Value Display

Resolution /

320 x 480 dots, 12 mm char. height

Number of places 31.000 / 3100

> 4%-place in the V, A, Hz and Ω measuring functions, depending on parameter setting

"OL" is displayed for ≥ 31,000 digits Overflow display

or ≥ 3100 digits

"-" (minus sign) is displayed Polarity display

if plus pole is connected to "L"

Measuring rate 10 and 40 measurements per second with

the Min-Max function except for the capacitance, frequency and duty cycle measur-

ing functions

Refresh Rate 2 times per second, every 500 ms

Power Supply

Service life

Battery module 3.7 V, 4000 mAh, LiPo

(approx. 25% self-discharge per year) Approx. 20 hours (without $M\Omega_{ISO}$ mea-

surement / R_{Lo} / R 4-wire)

Battery capacity display via battery sym-Battery indicator

bol: **____**, querying of momentary charge

level via menu function

Power OFF function The multimeter is switched off automatically:

- When battery voltage drops to below

approx. 3.6 V

- If none of the keys or the rotary switch are activated for an adjustable duration (10 to 59 min.) and the multimeter is not

in the continuous operation mode

Rechargeable battery modules can only be recharged externally.

l	Measuring Function	Nominal Voltage U _N	Resistance of the DUT	Service Life in Hours	Number of Possible Mea- surements with Nominal Current per VDE 0413
ı	٧ 🚤			20 1	
ı	V ~			15 ¹	
ı	RINS	100 V	1 ΜΩ	5	
ı		100 V	100 kΩ		300
ı		500 V	500 kΩ		60
		1000 V	2 ΜΩ		20

Times 0.7 for interface operation

Electrical Safety

Protection category II per EN 61010-1:2010/VDE 0411-

1:2011

Measuring category CAT III CAT IV Nominal Voltage 1000 V 600 V

Pollution degree

7.4 kV~ per EN 61010-1:2011/ Test voltage

VDE 0411-1:2011

Electromagnetic Compatibility (EMC)

Interference emission EN 61326-1:2013 class B

Interference immunity EN 61326-1:2013

Short-term measured value deviation of up to 10% may occur during electromagnetic interference thus reducing the specified operating quality.

Isolation Tester, Milliohmmeter, TRMS Multimeter, Short-Circuited Coil Tester

Ambient Conditions

0 °C to +40 °C Accuracy range

Operating temperatures (Storage temperature

-10 °C ... +50 °C with batteries)

-20 °C ... +50 °C with rubber holster Storage temperatures -25 °C ... +70 °C (without battery) 40 to 75%, no condensation allowed

To 2000 m Elevation

Deployment Indoors, except within specified ambient

conditions

Data Interface

Relative humidity

Туре Bluetooth 4.2 2.402 ... 2.480 GHz Frequency band Transmitting power max. 91 mW

Functions - Query measuring functions

and parameters

- Query momentary measurement data

Internal Measured Value Storage

Memory capacity 64 MBit for approx. 300,000 measured

values with indication of date and time

Mechanical Design

Impact resistant plastic (ABS) Housing 235 x 105 x 56 mm (without rubber **Dimensions**

holster)

Weight Approx. 0.7 kg with battery module Housing: IP 52 (pressure equalization by Protection

means of the housing)

Excerpt from table on the meaning of IP Codes

I	IP XY (1 st digit X)	Protection against foreign object entry	IP XY (2 nd digit Y)	Protection against the penetration of water
ı	0	not protected	0	not protected
ı	1	≥ 50.0 mm dia.	1	vertically falling drops
I	2	≥ 12.5 mm dia.	2	vertically falling drops with enclosure tilted 15°
ı	3	≥ 2.5 mm dia.	3	spraying water
ı	4	≥ 1.0 mm dia.	4	splashing water
ı	5	dust protected	5	water jets

Applicable Regulations and Standards

IEC 61 010-1 DIN EN 61 010-1 VDE 0411-1	Safety requirements for electrical equipment for measurement, control and laboratory use – Part 1: General requirements
DIN EN 61326-1 VDE 0843-20-1	Electrical equipment for measurement, control and laboratory use – EMC requirements – Part 1: General requirements
DIN EN 60529 VDE 0470-1	Test instruments and test procedures – degrees of protection provided by enclosures (IP code)
DIN EN 61557-1 VDE 0413-1	Electrical safety in low voltage distribution systems up to 1000 V a.c. and 1500 V d.c. – Equipment for testing, measuring or monitoring of protective measures Part 1: General requirements
DIN EN 61557-2 VDE 0413-2	Part 2: Insulation resistance
DIN EN 61557-4 VDE 0413-4	Part 4: Resistance of earth connection and equipotential bonding

METRAHIT IM XTRA with Accessory COIL Adapter 50mH (Z270F)



METRAHIT IM XTRA & METRAHIT IM E-DRIVE Isolation Tester, Milliohmmeter, TRMS Multimeter, Short-Circuited Coil Tester

Order Information

Designation	Tuno	Artiala Nurreber
Designation (2011 Por 1) its line in the last control of the last	Туре	Article Number
multimeter, milliohm-meter and isolation resistance tester (COIL Ready) with graphic display, Bluetooth, and software IZYTRONIQ Business Starter. R-ISO up to 1kV & m Ω @ 200 mA 2-wire & m Ω @ 200 mA 4-wire & m Ω @ 1 A 4-wire, delivery content comprises multimeter (M273D), push-button probe, cable set, kelvin-clips, hard case, rechargeable lithium battery, USB wall supply, calibration certificate, and SW licence.	METRAHIT IM XTRA BT	M273S
All-in-One Tester for electric machines, multimeter, milliohm-meter and isolation resistance tester (COIL Ready) with graphic display, Bluetooth, and software <code>IZYTRONIQ</code> Business Starter. R-ISO up to 1kV & m Ω @ 200 mA 2-wire & m Ω @ 200 mA 4-wire & m Ω @ 1 A 4-wire, delivery content comprises multimeter (M274B), push-button probe, cable set, each one kelvin-clip and kelvin-probe, hard case, rechargeable lithium battery, USB wall supply, calibration certificate, and SW licence.	METRAHIT IM E-DRIVE BT	M274S
Accessory cables and adapters		
Cable set (1 pair of measurement cables) 1.2 m, with VDE-GS mark, 600 V CAT IV 1 A ¹ , 1000 V CAT III 1 A ¹ 1000 V CAT II 16 A ²	KS17-2	GTY3620034P0002
Cable set with 2 mm diameter steel tips and 120 cm cable, 1000 V / CAT III	KS17-S	Z110H
Cable set including Remote probe, clamps and US test probes (1000 V CAT II / III 20 A)	KS-NTS	Z110W
Alligator clips (1 pair) for KS17-2 1000 V CAT III 16 A	KY95-3	Z110J
Current clamp sensor, 10 mA 100 A, 1 mV/10 mA, clamp opening: 15 mm dia.	WZ12B	Z219B
Kelvin clips (1 set of 2 ea.) for 4-pole connection of low-resistance DUTs, cable length: 150 cm	KC4	Z227A
Kelvin probes (1 set of 2 ea.) with double steel tips for 4-pole connection of low-resistance DUTs	KC27	Z227B
Set including 1 Kelvin clip and 1 Kelvin probe, as well as 2 stainless steel tips for 4-wire measurement, 120 cm cable length with 4 mm angle plugs	KC&S	Z227C
Rechargeable lithium polymer battery M27x 14,8 Wh	Z270A	Z270A
Rechargeable lithium polymer battery M27x 14,8 Wh	Z270G	Z270G
USB+Power Module M27x	Z270E	Z270E
Charger M27x	Z270L	Z270L
Coil adapter for interturn short circuit detection at inductivities from 10 µH to 50 mH	COIL Adapter 50mH	Z270F
Coil adapter for interturn short circuit detection at inductivities from 10 µH to 500 mH	COIL Adapter XTRA	Z270M
Probe with keys	Z270S	Z270S
AC/DC current clamp sensor, 5 mA 30 A, 100 mV/A	CP30	Z201B
AC/DC current clamp sensor, 0.5 30 A, 5 300 A, 10 mV/A, 1 mV/A	CP330	Z202B
AC/DC current clamp sensor, 0.5 100 A, 5 1000 A, 10 mV/A, 1 mV/A	CP1100	Z203B
AC/DC current clamp sensor, 0.5 125 A, 5 1250 A, 10 mV/A, 1 mV/A	CP1800	Z204A
Accessories for temporature messurement with resistance the mass return		
Accessories for temperature measurement with resistance thermometer Pt100 temperature sensor for surface and immersion measurements, -40 +600 °C	Z3409	GTZ3409000R0001
Pt1000 temperature sensor for surface and immersion measurements, –40 +600 °C Pt1000 temperature sensor for measurement in gases and liquids,	20409	0123409000N0001
-50 +220 °C (for servicing household appliances)	TF220	Z102A
Pt100 oven sensor, –50 +550 °C	TF550	GTZ3408000R0001
Protection and transport accessories		
Hard case with foam insert and compartments for 1 METRAHIT IM XTRA or METRAHIT IM E-DRIVE and 2 batteries, as well as 2 universal compartments for accessories.	HC40	Z270K
Replacement fuses		
Fuse F1 for current measuring ranges FF1 A/1000 V AC/DC (10 pcs.)	FF1 A/1000 V AC/DC	Z1090
FUSE ET TOLCUMENT MEASURING L'ANGES EET A/TOUGLY AC/OUTURES.		

¹ With plugged on safety caps

For additional information regarding accessories please refer to:

- Measuring Instruments and Testers catalog
- www.gossenmetrawatt.com

Edited in Germany • Subject to change without notice



GMC-I Messtechnik GmbH Südwestpark 15 90449 Nürnberg • Germany Phone: +49-911-8602-111 Fax: +49 911 8602-777 e-mail info@gossenmetrawatt.com www.gossenmetrawatt.com

Without plugged on safety caps